

Long-pulse Pre-amplifier Shutdown S-AB-P-064 Rev C

Intent: Use this procedure to shut down the Power Conditioning Units of the Preamplifiers used in LS1 or LS2.

Procedure:

-
- 1 Turn the key of the PU601C control unit to the “OFF” position.
- Verify the “HV ENABLE” light is OFF.
-
- 2 Start a remote desktop connection and exit the Pre-amp software.

Source	Computer Name
LS1	Brady
LS2	Preamp-sp-ls

(done)

Document Release:

Long-pulse Pre-amp Shutdown; S-AB-P-064

This document is a component of Vol. IX OMEGA EP System Startup and Shut Down, Chapter 2, Laser Sources Operating Procedures, S-AB-P-011.

Approval for release of this document into the PDM system was granted by:

S. Loucks; Director, LLE Engineering Division
S. Morse; OMEGA EP Project Manager
J. Edwards; OMEGA EP System Engineer
J. Puth; OMEGA EP Laser Sources Subsystem Engineer
D. Vickery; OMEGA EP Laser Sources Engineer