

Short-Pulse Stray Light Management




R. JUNGQUIST

University of Rochester, Laboratory for Laser Energetics

Summary/Conclusions


Reflections off of diagnostics in the path of the short-pulse beams create a threat that must be managed



- Diagnostic qualification requires stray light analysis and mitigation strategies when used opposite a short-pulse beam
- To prevent the retroreflection from damaging system optics, flat surfaces positioned within 360 mm of the short-pulse focal spot must either
 - be tilted an appropriate angle
 - or replaced with an appropriate shaped surface
 - conical surface with a 5.5° base angle
 - care taken not to direct short-pulse beam toward UV beam optics
 - B-integral limit determines how much short-pulse energy can impinge on UV optics


G9496

Threats are determined by calculating fluence on optics in the beam train compared to the incoming fluence




G9498

The mitigation strategy is to redirect the short-pulse reflection using angled surfaces on diagnostics and target positioners




G9500

Example analysis results: ten-inch manipulator target positioner with LLNL target holder for OMEGA




G9502

An extensive optomechanical model has been developed for both target chambers




G9497

A safe keep-out distance from the target chamber center can be found to avoid damaging short pulse




G9499

A secondary threat can exist when sufficient short-pulse light hits the UV optics after redirection



G9501

Example analysis results: ten-inch manipulator target positioner holder for OMEGA EP backlighter



G9503