


The Release Behavior of Diamond Shocked to 15 Mbar



M. C. Gregor
University of Rochester
Laboratory for Laser Energetics

45th Annual Anomalous
Absorption Conference
Ventura, CA
14–19 June 2015

Summary

The shock and release behaviors of the NIF diamond ablator material were measured



- The National Ignition Facility (NIF) uses ultra-nanocrystalline high-density carbon (HDC) ablators
- Knowledge of the diamond Hugoniot and release behavior is critical for inertial confinement fusion (ICF) ignition target designs
- Release data are obtained by impedance matching with known standards
- Models for both the single-crystal (SC) diamond and HDC release are constrained by the experimental data
- The SC diamond release into liquid deuterium is accurately modeled using *SESAME 7830*
- The release data for both SC diamond and HDC will aid in the development of more-precise models for ICF target designs

Collaborators





T. R. Boehly, C. A. McCoy, D. N. Polsin, and D. D. Meyerhofer

**University of Rochester
Laboratory for Laser Energetics**



D. E. Fratanduono, P. M. Celliers, and G. W. Collins

Lawrence Livermore National Laboratory



Equation-of-state data are obtained from the impedance-matching technique





Equation-of-state data are obtained from the impedance-matching technique





Equation-of-state data are obtained from the impedance-matching technique





Equation-of-state data are obtained from the impedance-matching technique





Equation-of-state data are obtained from the impedance-matching technique



Release data are obtained using the impedance-matching technique between known standards





Release data are obtained using the impedance-matching technique between known standards



Motivation

Initial NIF shock-timing experiments revealed inaccuracies in the ablator release model





The glow-discharge polymer (GDP) equation-of-state model was corrected using release data into liquid D₂.^{**}

*H. F. Robey *et al.*, *Phys. Plasmas* **19**, 042706 (2012).



S. Hamel *et al.*, *Phys. Rev. B* **86, 094113 (2012).

The impedance-match method was used to measure the SC diamond release into liquid D₂





The release isentrope constructed using *SESAME 7830* agrees with the experimental data.

The single-crystal diamond release model is constrained using multiple standards




*M. D. Knudson and M. P. Desjarlais, Phys. Rev. B **88**, 184107 (2013).
 M. A. Barrios *et al.*, Phys. Plasmas **17, 056307 (2010).
 ***M. D. Knudson and R. W. Lemke, J. Appl. Phys. **114**, 053510 (2013).
 †M. D. Knudson, Sandia National Laboratories, private communication (2015).

Experiments with HDC provide both Hugoniot and release measurements





- Instantaneous shock velocities in HDC are determined using an unsteady wave correction*

The HDC Hugoniot was measured up to 20 Mbar



The HDC release model is constrained using four materials including deuterium



*M. D. Knudson and M. P. Desjarlais, Phys. Rev. B **88**, 184107 (2013).

M. A. Barrios *et al.*, Phys. Plasmas **17, 056307 (2010).




***M. D. Knudson and R. W. Lemke, J. Appl. Phys. **114**, 053510 (2013).

†M. D. Knudson, Sandia National Laboratories, private communication (2015).

The shock and release behaviors of the NIF diamond ablator material were measured

- The National Ignition Facility (NIF) uses ultra-nanocrystalline high-density carbon (HDC) ablaters
- Knowledge of the diamond Hugoniot and release behavior is critical for inertial confinement fusion (ICF) ignition target designs
- Release data are obtained by impedance matching with known standards
- Models for both the single-crystal (SC) diamond and HDC release are constrained by the experimental data
- The SC diamond release into liquid deuterium is accurately modeled using *SESAME 7830*
- The release data for both SC diamond and HDC will aid in the development of more-precise models for ICF target designs

Shock velocities for impedance matching are measured using a time-resolved VISAR



The single-crystal diamond release model is constrained using multiple standards

