

Power Balance on a Multibeam Laser

S. SAMPAT, J. H. KELLY, T. Z. KOSC, A. L. RIGATTI, J. KWIATKOWSKI, W. R. DONALDSON, M. H. ROMANOFKY, L. J. WAXER, R. DEAN, and R. MOSHIER

University of Rochester, Laboratory for Laser Energetics

Summary


The 30-kJ OMEGA Laser System has been power balanced to 3% rms across 60 beams

- Maximizing inertial confinement fusion (ICF) target irradiation uniformity is a key requirement for successful target implosion
- ICF target-implosion simulations indicate <1% rms intensity balance over any 100-ps interval
- Power balance is assessed using a time-resolved and spatially integrated measurement of each of the 60 beamlines
- Dedicated campaigns have improved power balance from over 6% rms to less than 3% rms on cryogenic ICF experiments

G11828a

Conditions necessary to achieve power balance

- Equal gain at each amplification stage
- Equal losses at each amplification stage
- Equal frequency-conversion efficiency
- Equal beam timing



G11828a


Passive losses are identified using calorimetric measurements

- Up to ten calorimeters are marched down each leg and each beamline of OMEGA
- A low-energy, low-power infrared (IR) pulse is used to measure transmission
- Stage-by-stage measurement of passive transmission is then calculated
- IR transmission of FCC's was also measured



G11790a

Other sources of incidental losses were also identified




Transmission losses of up to 3% were addressed.

G11842a

*LCP: liquid crystal polarizer

Beam timing is measured during routine maintenance periods




Beam timing is maintained to <5 ps.

G24322c

PLAS: path-length adjustment system
PMT: photomultiplier tube
AMP: Nd-glass amplifier

OMEGA's 60 beams are generated via splitting and subsequent amplification of a single seed beam



G11828a

*FCC: frequency-conversion crystal

Small-signal gain (SSG) measurements are used to equalize gains at each stage


- Three consecutive iterations to optimize gain balance by stage
- Gain is measured by stage for each amplifier leg and beamline
- Resulting data isolate poorly performing amplifiers
 - spotted rod jackets, dirty reflectors, corroded deionized water connectors
 - defective amplifiers are addressed after each SSG iteration

Stage	Goal rms (%)	Typical rms (%)
A	<0.5	0.3
B	<0.5	0.3
C	<0.5	0.3
D	<1.0	0.9
E	<1.0	0.9
F	<1.0	0.7



G11828a

Compensating losses with amplifier gain results in poor power balance




Rough guide: 1% unbalanced loss results in 2% pulse tilt.

G11837a

Frequency conversion performance equalization was improved by reducing the number of sensitive variables

- Conversion sensitivity to several variables: crystal tunings, thicknesses, transmissions, temperatures, separations (broadband operation), input polarizations, etc., for each crystal
- The 60 second-tripler crystals used for broad-bandwidth frequency conversion were removed to eliminate them as a source of imbalance
- A 60-beam tripler-tuning optimization was performed to reduce tripler-tuning variation to $\pm 40\text{-}\mu\text{rad}$ rms




For shots with equal IR-input energy rms, the UV energy rms improved from 2.1% rms to 1.7% rms.

G11865

Dedicated campaigns demonstrate improved power balance

- Equal gain at each amplification stage
- Equal losses at each amplification stage
- Equal frequency-conversion efficiency
- Equal beam timing



Improvement in picket and drive balance from >6% to 3%.

G11795a