


A Reduced-Autocorrelation Phase-Plate Design for OMEGA and the NIF



J. Marozas
Presented by R. S. Craxton
University of Rochester
Laboratory for Laser Energetics

43rd Annual Meeting of the
American Physical Society
Division of Plasma Physics
Long Beach, CA
29 October–2 November 2001

Summary

High-pass phase plates provide an effective means to reduce the nonuniformity in low- ℓ modes




High-pass phase plates:

- reduce the nonuniformity where SSD has a modest effect;**
- work in the presence of typical near-field aberrations; and**
- provide benefit for both OMEGA and the NIF.**

Outline

- **High-pass phase plate design scheme**
- **Phase aberrations**
- **High-pass design for the NIF**
- **High-pass design for OMEGA**

The high-pass phase-plate design process is initialized by filtering the far-field speckle pattern




There are two methods to design reduced-autocorrelation phase plates



- The first method directly minimizes the local autocorrelation of the phase-plate elements:
 - reduces the nonuniformity by a modest factor of 2; and
 - provides a far-field shape governed by the shape of the discrete elements.
- The second method directly high-pass filters the far-field speckle pattern:
 - reduces the nonuniformity by as much as factor of 5; and
 - produces a far-field shape that is user-selectable.


A high-pass phase plate was designed for OMEGA to reduce all modes $\ell \leq 200$



- Static phase aberrations reduce the benefit of the high-pass phase plates.
- Time-varying phase terms like SSD do not adversely affect the high-pass phase plates.

The strength of a static phase aberration is expressed in terms of times diffraction limited (DL)

- The power spectrum has the assumed form $\propto \left(\frac{a}{\lambda^n}\right)^2$



$$D_{95} \cong 83 \mu\text{m}$$


$$D_{DL} = 6.9 \mu\text{m}$$

- The amplitude a is varied, and the strength of the aberration is measured in terms of times diffraction limited:

$$\text{times DL} = \frac{D_{95}}{D_{DL}}$$


A factor-of-1.5 reduction in nonuniformity is still achieved in the presence of a strong phase aberration in the mode range $20 \leq \ell \leq 60$

- NIF design
- When aberrations are present, the reduction factor decreases from 4 to 1.5.




The nonuniformity reduction factor is relatively insensitive to the phase aberrations in the mode range $10 \leq \ell \leq 40$

- OMEGA design



An OMEGA far-field simulation with measured phase aberration yields a factor-of-2 reduction in the nonuniformity after 300 ps

- 1-THz SSD and PS applied
- Measured near-field aberration applied: 12 times DL
- Summed over mode range $12 \leq \ell \leq 25$



Summary/Conclusions

High-pass phase plates provide an effective means to reduce the nonuniformity in low- ℓ modes



High-pass phase plates:

- reduce the nonuniformity where SSD has a modest effect;**
- work in the presence of typical near-field aberrations; and**
- provide benefit for both OMEGA and the NIF.**