


Radiative Transport Modeling Relevant to Cryogenic Implosion Simulation and Diagnosis



R. Epstein *et al.*
University of Rochester
Laboratory for Laser Energetics

49th Annual Meeting of the
American Physical Society
Division of Plasma Physics
Orlando, FL
12–16 November 2007

Summary

The continuum x-ray spectra of cryogenic target implosions should provide T_e and ρR diagnostic information



- Spectra simulated with low-order-implosion nonuniformity display the observed continuum temperatures and intensities.
- Low-order-implosion nonuniformity reduces the shell absorption at the soft end of continuum spectra, but not enough to fully account for the low measured absorption.
- Possible explanations for the low measured absorption includes opacity reduction due to strongly coupled plasma effects.

Collaborators





J. A. Delettrez
V. N. Goncharov
J. P. Knauer
P. W. McKenty
F. J. Marshall
D. Li
P. B. Radha
S. P. Regan
H. Sawada
B. Yaakobi

University of Rochester
Laboratory for Laser Energetics

The continuum-spectrum peak shifts with shell areal density in a simple two-layer shell model


Cryo shell at peak compression with a variable source/absorber split (parameter f).



The spectral temperature and hard-x-ray intensity of the core of shot 47206 are simulated accurately




Shot 47206: 10- μm shell, DD
 $\langle \rho R \rangle_p = 202 \text{ mg/cm}^2$




The simulated spectrum of the cryogenic high- ρR implosion is formed by a nonuniform source

Cryo shot 47206 profiles at peak neutron emission, $t = 4.08$ ns




DRACO/Spect3D time-resolved spectra of high- ρR implosions are very similar from all viewing angles


DRACO/Spect3D,
OMEGA cryo shot 47026




DRACO/Spect3D x-ray images of high- ρR cores match the measured size of the of the spectral source



The compressed-shell opacity model must include all relevant high-density strong-coupling effects



Opacity models



- The AOT Gaunt factor is the exact degenerate coulomb Fermi-Dirac result of Nakagawa *et al.**
- The ion-sphere potential replaces the coulomb potential in strongly coupled plasmas ($\Gamma > 1$).


Strongly coupled ion-sphere opacity reduction is potentially very significant.

The continuum x-ray spectra of cryogenic target implosions should provide T_e and ρR diagnostic information



- Spectra simulated with low-order-implosion nonuniformity display the observed continuum temperatures and intensities.
- Low-order-implosion nonuniformity reduces the shell absorption at the soft end of continuum spectra, but not enough to fully account for the low measured absorption.
- Possible explanations for the low measured absorption includes opacity reduction due to strongly coupled plasma effects.

The compressed-shell opacity model must include all relevant high-density strong-coupling effects




- The AOT Gaunt factor is the degenerate exact coulomb potential, Fermi-Dirac result of Nakagawa *et al.*

Strongly coupled ion-sphere opacity reduction is potentially very significant.


The degeneracy of compressed-shell electrons substantially reduces the free-free opacity

DD $kT = 100$ eV

ff Opacity degeneracy effect




ff Opacity degeneracy effect



- Above $h\nu = 2\varepsilon_F$, only the initial electron states are degenerate.

Simulated spectra similar to the measured spectra are obtained with modified thermal-transport models



◆ Grating spectrometer
* Crystal spectrometer