


Numerical Evaluation of Subtangential Focusing in OMEGA Target Implosions



P. W. McKenty
University of Rochester
Laboratory for Laser Energetics

53rd Annual Meeting of the
American Physical Society
Division of Plasma Physics
Salt Lake City, UT
14–18 November 2011

Summary

Direct-drive phase plates require precise design to achieve the necessary imprint and laser–plasma interaction (LPI) mitigation



- **Subtangential focusing leads to higher laser absorption**
- **Hydrodynamic instabilities are enhanced by reduced target illumination uniformity**
- **Bifocal phase plates are being examined to evaluate their applicability to OMEGA and NIF experimental platforms**


Collaborators



**F. J. Marshall, D. D. Meyerhofer, T. J. Kessler,
D. H. Froula, I. V. Igumenshev, D. H. Edgell
W. Seka, and R.L. McCrory**

**Laboratory for Laser Energetics
University of Rochester**

Laser absorption can be increased by implementing subtangential focusing






Positives

- Decreased refraction
- Reduced crossed-beam energy transfer



Negatives

- Enhanced overlap nonuniformity
- Reduced imprint smoothing




Subtangential-focus experiments are drawn from previous OMEGA capsule implosions




Subtangential-focus experiments showed a relative yield improvement at tighter focus but 2× reduction in yield performance overall



Defocused phase plates lead to higher levels of imprint nonuniformities and lower target performance



DRACO simulations of an $F = 0.8$ OMEGA cryogenic implosion show degraded target performance





$F = 1.0$

- Yield over clean 30%
- ρR over clean 92%

$F = 0.8$



- Yield over clean 21%
- ρR over clean 70%

Single-focus phase plates can only straddle the desired regions of imprint and LPI control





Bifocal phase plates, coupled with co-propagation of spliced pulses, can deliver two-step laser zoom

- Two-state phase modulation yields efficient energy transfer
- Sensitivity to focal-spot shape and profile is reduced
- Smaller focal spot decreases CBET for the main laser pulse
- Reduced phase gradients lower laser-damage probability



Two-step zooming can provide both imprint and LPI mitigation while maintaining target performance



Direct-drive phase plates require precise design to achieve the necessary imprint and laser–plasma interaction (LPI) mitigation

- **Subtangential focusing leads to higher laser absorption**
- **Hydrodynamic instabilities are enhanced by reduced target illumination uniformity**
- **Bifocal phase plates are being examined to evaluate their applicability to OMEGA and NIF experimental platforms**