


Application and Analysis of the Isoelectronic Line-Ratio Temperature Diagnostic in a Planar Ablating-Plasma Experiment at the National Ignition Facility



Shot N150520: 23° and 30° beams

NIF x-ray spectrometer streaked spectrum
(uncalibrated)



R. Epstein
University of Rochester
Laboratory for Laser Energetics

57th Annual Meeting of the
American Physical Society
Division of Plasma Physics
Savannah, GA
16–20 November 2015

The isoelectronic Co/Mn He $_{\alpha}$ line ratio is a good temperature diagnostic for ablating plasmas

- The Co/Mn He $_{\alpha}$ line ratio was used to measure the electron temperature in planar experiments performed to study the beam angle-of-incidence dependence of the two-plasmon–decay (TPD) instability
- The density sensitivity of this line ratio is a source of systematic error and a consideration in choosing microdot materials
- Spectrum simulations show that the He $_{\alpha}$ line ratio is only modestly affected by self-absorption

Collaborators



**M. J. Rosenberg, A. A. Solodov, J. F. Myatt, S. P. Regan,
W. Seka, and M. Hohenberger**

**University of Rochester
Laboratory for Laser Energetics**

M. A. Barrios and J. D. Moody


Lawrence Livermore National Laboratory

Temperatures in two planar experiments performed at the National Ignition Facility (NIF) were inferred from isoelectronic line ratios from embedded Co/Mn microdots



Shot N150520: 23° and 30° beams
(32 beams total)

Shot N150521: 45° and 50° beams
(60 beams total)




- *PrismSPECT** for parameter (T_e , ρ) surveys
 - detailed atomic modeling
 - self-absorption modeled as local photon-escape probabilities in spherical geometry
- *Spect3D** simulations include the same detailed atomic model plus
 - microdot conditions obtained from T_e , ρ histories from *DRACO* CH foil simulations
 - realistic microdot geometry with the actual 7° viewing angle
 - nonlocal coupling of radiation with atomic kinetics


Spectra were measured through the entire duration of the laser pulse by the NXS spectrometer

Shot N150520: 23° and 30° beams

NIF x-ray spectrometer streaked spectrum
(uncalibrated)




NXS calibrated spectrum at 2.4 ns





- Only the Mn and Co emission are simulated
- Line ratios are based on 200-eV spectral integrals

Consistent Co/Mn microdot line ratios have been obtained using *DRACO* T_e, ρ trajectories with *PrismSPECT* and *Spect3D* modeling



- *Spect3D* simulations, including nonlocal radiation transport, are based on the axially expanded microdot shape and the actual 7° viewing angle
- Very similar results are obtained for free-escape, local, and nonlocal photon-transport modeling



The isoelectronic He_α line ratio* is primarily a function of electron temperature T_e , depending weakly on n_e and optical thickness



- The measured Co/Mn He_α line ratio indicates $T_e \approx 4$ keV at $n_c/4$, compared to $T_e \approx 3$ keV predicted by *DRACO* CH foil simulations


There is little effect of self-absorption on the Co/Mn He $_{\alpha}$ ratio for quarter-critical microdot conditions

- Use microdot-scale spheres to test the effects of self-absorption on optically thick lines
 - line attenuation
 - pumping of the He $_{\alpha}$ -emitting states



- The supply of emitted He $_{\alpha}$ photons is determined by the $1s-2p$ collisional excitation rate
- He $_{\alpha}$ photon absorption is followed by re-emission with near-certain probability

Temperature measurement based on the Co/Mn line ratio does not require a stringent density constraint




- Temperature measurement from density-dependent line ratios requires some prior knowledge of the density
- Alternative microdot materials offer higher temperature sensitivity at the expense of higher-density sensitivity


The isoelectronic Co/Mn He $_{\alpha}$ line ratio is a good temperature diagnostic for ablating plasmas

- The Co/Mn He $_{\alpha}$ line ratio was used to measure the electron temperature in planar experiments performed to study the beam angle-of-incidence dependence of the two-plasmon–decay (TPD) instability
- The density sensitivity of this line ratio is a source of systematic error and a consideration in choosing microdot materials
- Spectrum simulations show that the He $_{\alpha}$ line ratio is only modestly affected by self-absorption

He α line ratios from lower-Z elements, e.g., V/Sc, are more temperature sensitive than Co/Mn





- Density 0.005 g/cm 3



- Temperature dependence is primarily from ionization balance and collisional 1s–2p excitation
- Mn and V He α are not in the same NXS channel

The total δT temperature estimate uncertainty depends on the line ratio measurement uncertainty δr and also on a density constraint $\delta \log_{10} \rho$



- Density 0.005 g/cm^3 , temperature $\approx 3.0 \text{ keV}$